



Skylight/Chimney Flashing (Uphill)



Notes:

- Do not fasten down the panels within 24" uphill from the skylight.
- For chimney installation use a Reglet and Anchors.